




QUICK START GUIDE

LG Digital Signage (MONITOR SIGNAGE)

32SM5C	43SM5C	49SM5C	55SM5C	65SM5C
32SM5KC	43SM5KC	49SM5KC	55SM5KC	65SM5KC
		43SM3C	49SM3C	55SM3C



⊕ Depending upon country

(Image may vary depending on model)

Unpacking

Check your product box for the following items. If there are any missing accessories, contact the local dealer where you purchased your product. The illustrations in this manual may differ from the actual product and item.



MFL69446150

P/No: MFL69446150 (1609-REV00)



English

You can download the web manuals for this product at the following websites. (Keyword : SM5C, SM3C, SM5KC)


- World Wide : www.lgecommercial.com / www.lg.com



SuperSign : www.lgecommercial.com/supersign




32SM5*	43SM5*	49SM5*	55SM5*
43SM3C	49SM3C	55SM3C	



⊕ **SM5C, **SM3C


NOTE


Image shown may vary depending on model.
All connection cables & devices shown in the picture are not included along with the set.








65SM5*







NOTE

Image shown may vary depending on model.

IN002043