




MAXHUB XT20-VB Kit



Quick Start Guide

V1.0

MAXHUB

Table of Contents

I. Package Contents	02
1. XBar U50 Package	03
2. XC25T Mini-PC Package	04
3. TCP30T Touch Console Package	04
II. Basic Connection	05

Thank you for choosing **MAXHUB** product.

To ensure that you are able to fully utilize the capabilities of the product, we ask that you please read this quick start guide carefully and thoroughly before using the device. Should you have any questions or require assistance, please do not hesitate to contact our technical support team for guidance.

Safety Information

• Be Careful of Electric Shock or Fire

- (1) This device is not waterproof, please keep it dry; if water is immersed in this product, please shut down immediately and contact the customer service center according to the prompt provided by the customer service center before using it again.
- (2) Never place this device and accessories near the burning flames or other heat sources, including direct sunlight.
- (3) This device should be turned off and unplugged before lightning storms.

• Be Careful of Short Circuit or Catching Fire

- (1) Before connecting this device to an electrical outlet, please make sure that the power supply voltage matches the voltage value printed on the back or bottom of the product. Never connect the product to an electrical outlet when the voltage is different.

• Be Careful of Injury or Damage this Speaker

- (1) Never place this device or any objects on a power cord or other electronic devices.
- (2) If this product is transported at a temperature below 5°C, please unpack the product and wait until the temperature reaches room temperature before connecting it to a power outlet.
- (3) This product comes with sharp objects, please handle it carefully so as to avoid injury to the user or scratching the appearance of the product or damaging the internal parts of the product.

• Be Careful Overheat

- (1) Never install this device in an enclosed space. Always leave at least 4 inches space around the product for ventilation.

Care For the Product

- (1) Clean this device only with a piece of microfiber cleaning cloth.

Care For the Environment

- (1) This device applies recyclable high-performance materials and components. Never dispose of this product with other household wastes. Please understand the local regulations on the sorting collection of electronic, electrical products and batteries.
- (2) Proper disposal of these products helps to avoid potential negative effects on the environment and human body health.

Maintenance & Servicing

- (1) Please contact professional service personnel for all repair services.
- (2) Please do not insert any sharp object into the inside of the device.
- (3) Please do not drop or hit the device to avoid damaging it.

Regulatory Notice

Regulatory and certification information can be found in the provided **Regulatory Notices** document or at the official website: <https://www.maxhub.com/resource-center/>


Technical Support

Please visit the official website: www.maxhub.com for more information about the product documents, software, firmware upgrade, FAQs, etc. Should you have any questions or concerns, please do not hesitate to contact our technical support team for help.


I. Package Contents

The XT20-VB Kit includes three parts:


- 1. XBar U50 package**
- 2. XC25T Mini-PC package**
- 3. TCP30T Touch Console package.**



XBar U50 Package *1



XC25T Mini-PC Package *1



TCP30T Touch Console Package *1


1. XBar U50 Package




XBar U50 ×1




Quick Start Guide ×1



Positioning Card ×1




Remote Control
(AAA battery
not included)



Power Adapter ×1
(1.5 m / 4.92 ft)




Power Cord ×3
(1.5 m / 4.92 ft)



USB B-A Cable ×1
(3 m / 9.84 ft)



Mounting Bracket ×1



TV-Clip Mount ×1



Double-Sided Tape ×2
(One is on the TV-clip mount)



TV-Clip Screw ×1
(KM3×6)



Wing Thumb Screw ×2
(1/4-20)




Wall Anchor ×4
(6×32)




Wall Screw ×6
(KA3×30)


2. XC25T Mini-PC Package




Mini PC ×1



Wall Bracket ×1



Power Adapter ×1



Quick Start Guide ×1



HDMI Cable ×2 (3 m / 9.84 ft)



Power Cord ×3 (1.8 m / 5.91 ft)



Screwdriver ×1



M4 Screw ×4



Wall Anchor ×4



Self-tapping Screw ×4


3. TCP30T Touch Console Package



USB Type-C Cable ×1 (1.8 m / 5.9 ft)



Ethernet Cable ×1 (7.5 m / 24.61 ft)



Touch Control ×1

NOTE

The power cord may vary in different regions, please refer to the actual product.

II. Basic Connection

The wiring diagram for the basic connection is shown below:

