



CP965 Hardware Introduction

The table lists each feature numbered in the figures.





	Item	Description
1	Mute Touch Keys	• Indicate phone statuses. • Tap to mute/unmute.
2	Touch Screen	5 inches (720 x 1280) capacitive (5 points) touch screen. You can tap to select items and navigate menus.
3	Volume Touch Keys	Adjust the volume of the speaker, ringer, or media.
4	Home Touch Key	Tap it to return to the idle screen.
5	USB Type-A Port	• Allow you to connect a USB flash drive (optional) to your phone so you can record calls/conferences and play back recorded files. • Allow you to connect expansion PSTN box(es) (optional) to experience calls in PSTN. Up to two cascaded expansion PSTN boxes can be connected, so you can conveniently experience the local five-way conference in excellent speech quality with PSTN.

		• Allow you to charge the Bluetooth Wireless Microphone CPW25 or DECTWireless Microphone CPW65.
6	Security Slot	Allow you to connect a universal security cable to your phone so you can lock down your phone. You cannot remove the phone after it is locked.
7	USB Type-C Port	Allow you to connect a PC and turn the CP965 into an external speaker and microphone for your PC.
8	Network Port	Enable you to connect the phone to a wired network.