

LED Indicators

LED Indicators on VP59/MP58 (E2)/MP56 (E2)/MP54 (E2)/MP52 (E2)

LED Status	Description
Red	The phone is initializing.
Fast-flashing red (300 ms)	The phone is ringing.
Slowly flashing red (1 s)	The phone receives a voicemail or misses a call.
Red for 500 ms and off for 3 s alternately	The phone enters power-saving mode.

The above introduces the default LED status. Your system administrator can configure the status of the power LED indicator.

LED Indicators on BTH58

LED Status	Description
Solid green	The handset charges fully.
Green for 1 s	The handset turns on.
Fast-flashing orange	The handset is paired with the phone.
Slowly flashing orange	The handset is reconnecting.
Orange for 1 s	The handset is connected to the phone.
Fast-flashing red	Receives a call, and the handset is not on the phone handset cradle.
Slowly flashing red	The handset's battery is low.
Solid red	The handset is charging.
Red for 3 s	The handset turns off automatically.
Red and green flashing alternately	The handset is finding the phone.
Red, green, and orange flashing alternately	The handset is upgrading.

Mute Touch Key LED Indicators on CP965

LED Status	Description
------------	-------------

Solid red	The phone is initializing. The phone is muted.
Flashing red	The phone is ringing.
Solid green	The phone is placing a call. There is an active call on the phone.
Off	The phone is powered off. The phone is idle.