

Pair VCM36-W with Yealink MeetingBar

Introduction

The Yealink VCM36-W is a cutting-edge wireless video conferencing microphone designed to meet diverse meeting room requirements. Equipped with a built-in 3-microphone array, the VCM36-W offers a 20-foot (6-meter) 360° voice pickup range. Its advanced echo cancellation and noise suppression technology effectively reduce ambient noise by up to 90 dB, ensuring superior audio quality during full-duplex calls.

The VCM36-W delivers comprehensive audio coverage suitable for conference rooms of all sizes. With simple one-step pairing, it is easy to set up and offers up to 12 hours of battery life in conference mode and 7 days in standby mode.

The VCM36-W comes with a wireless charging dock, allowing the microphone to be recharged conveniently. Its portable design enables users to adjust its placement as needed during meetings, providing unparalleled flexibility and convenience.

Before You Begin

- For the compatibility of VCM36-W and Yealink MeetingBar, refer to [Rooms Accessories Compatibility Lists](#).
- For how to install the VCM36-W, refer to [Yealink VCM36-W Quick Start Guide](#).

Connect VCM36-W to Yealink MeetingBar


Before You Begin

On the home screen, select **Wireless AP** in **More > Settings > Device Settings > Network (default password: 0000) > Wireless AP**.

To connect VCM36-W to Yealink MeetingBar

1. Connect VCM36-W to the USB-A port of Yealink MeetingBar with a USB cable (A-C).

MeetingBar




2. For Microsoft Teams: On the home screen, select **More > Settings > Device Settings > Audio > Wireless Microphone**.

For Zoom: On the home screen, tap **Settings > General > System Settings > Audio > Wireless Microphone**.

For General Mode (BYOM): On the home screen, select **More** or  **> Settings > Audio > Wireless Microphone**.

After disconnecting the USB cable (A-C), the VCM36-W can be used normally.



Update VCM36-W

Before You Begin

Make sure the VCM36-W is powered sufficiently before upgrading.

To update VCM36-W

- After pairing the VCM36-W to the Yealink MeetingBar, the built-in firmware will be obtained from the Yealink MeetingBar. For more information, refer to [Firmware Update](#).

Unbind VCM36-W

- For Microsoft Teams: On the home screen, select **More > Settings > Device Settings > Audio > Wireless Microphone** to unbind the connected VCM36-W.

For Zoom: On the home screen, tap **Settings > General > System Settings > Audio > Wireless Microphone** to unbind the connected VCM36-W.

For General Mode (BYOM): On the home screen, select **More or**  **> Settings > Audio > Wireless Microphone** to unbind the connected VCM36-W.

FAQ

- Can VCM36-W and the built-in microphone of the Yealink MeetingBar pick up sound at the same time?

The VCM36-W is an expansion microphone that simultaneously picks up sound with the built-in microphone. The meeting will automatically select the VCM36-W or the built-in microphone of Yealink MeetingBar to pick up sound according to the position of the sound source. For more information about the sound pickup of the built-in microphone and external microphone, please refer to [Can the built-in microphone and external microphone pick up sound at the same time?](#)

2. After connecting Yealink MeetingBar to the VCM36-W, the VCM36-W cannot pick up the audio/ there is no response when touching the VCM36-W mute button.

Yealink MeetingBar does not support the simultaneous use of multiple different types of microphones, such as the simultaneous use of VCM35 and VCM36-W.

Please check whether other microphones are connected at the same time.

3. How to reset the VCM36-W microphone?

The VCM36-W microphone does not support reset.