

Pair VCM36-W with MVC

Introduction

The Yealink VCM36-W is an innovative wireless video conferencing microphone designed to accommodate various meeting room needs. With a built-in 3-microphone array, the VCM36-W has a 20ft (6m) and 360° voice pickup range. It features Yealink's high-quality echo cancellation technology and noise cancellation, effectively filtering out up to 90dB of ambient noise to provide a high-quality audio experience during full-duplex calls. The VCM36-W's high-quality pickup technology enables it to offer a full range of audio coverage for all sizes of conference rooms. The VCM36-W is easy to use with a single pairing, with up to 12 hours of battery life in conference mode and 7 days of standby time. The VCM36-W WIFI microphone is equipped with a charging dock that allows you to charge the microphone wirelessly, and you can change its deployment position at any time while using it to suit your needs.

VCM36-W Compatibility

For the VCM36-W compatible devices, please refer to [Rooms Accessories Compatibility Lists](#).

Connect MVC to VCM36-W

Method 1: Pair directly

1. Use a USB cable to connect the Type-C port of VCM36-W to the USB port (PC port) of the Yealink UVC Camera. When pairing, the mute LED indicator of the VCM36-W flashes yellow quickly. After the pairing is successful, you can see on the display connected to Yealink mini-PC: The wireless microphone pairing is successful, and you can check the VCM36-W on the Yealink RoomConnect application.
2. After disconnecting the cable, you can use the VCM36-W.

Method 2: Pairing via Yealink RoomConnect application

1. Connect the Type-C port of the VCM36-W to the PC/Yealink mini-PC via a USB cable.
2. Connect the Yealink UVC Camera to the same PC/Yealink mini-PC via a USB cable.
3. Run the Yealink RoomConnect application on your PC. After pairing successfully, the VCM36-W card will appear on the Yealink RoomConnect application.
4. After disconnecting the cable, you can use the VCM36-W.

! VCM36-W currently only supports wired pairing.

Unpair VCM36-W


Method 1:

Pair the VCM36-W with a new device to cancel the pairing of the VCM36-W with the original device.

Method 2:

Turn off the AP (wireless hotspot) of the Yealink UVC Camera to cancel the VCM36-W pairing and the original device.

1. Open the Yealink RoomConnect application and select the paired device.
2. Select **Settings**.
3. Disable **AP**.



FAQ

Can VCM36 and MVC's built-in microphone pick up sound at the same time?

The VCM36 is an expansion microphone that supports simultaneous sound pickup with the built-in microphone. You can set which microphone to use for pickup on the Yealink MTouch Touch Panel.

After connecting the MVC to the VCM36, the VCM36 cannot pick up the audio, and there is no response when touching the VCM36 mute button.

MVC does not support the simultaneous use of multiple microphone devices. Please check whether other microphones are connected at the same time.

How to reset the VCM36 microphone?

The VCM36 microphone has no reset feature.